#### Copyright © Shanghai eSurvey GNSS Co., Ltd. 2021. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Shanghai eSurvey GNSS Co., Ltd.

#### **Trademarks and Permissions**

O-survey and other eSurvey trademarks are trademarks of Shanghai eSurvey GNSS Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

#### Notice

The purchased products, services and features are stipulated by the contract made between eSurvey and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.



# 1 Software

# 1.1 Overview

The main software interface is as follows:



### **Solution status**

- : no satellite signal.
- : single solution.
- FLT 1 : float solution.

RTK

- SBAS status (the wide-area differential augmentation system (satellite- based augmentation system)).
  - : fixed solution. The number after **RTK** refers to delay.

### Main menu

ani

- Start Task: see Start a Task for details.
- Configure Implement: see Configure the Implement for details.
- Calibrate Vehicle: see Calibrate the Vehicle for details.
- Communication Mode: see Set Communication Mode for details.
- Diagnose: see Diagnose for details.
- Settings: see Settings for details.





# 1.2 Start a Task

To start a task, do one of the following:

1. Press main menu **Start Task**:



- 2. Do one of the following:
  - $\circ$  Create a new task.
  - Resume the last task.
  - $\circ$  Load a task.
  - Get a task from the server platform.



### 1.2.1 Create a New Task

It is used to select a guidance line to guide your work and create a new task.

See Set Guidance Lines for details.

To create a new task, do the following:



- 2. Select one of the following guidance lines:
  - AB line mode
  - o A+ line mode
  - o Pivot mode
  - o Grid mode
  - o Contour mode
  - Land measurement mode
  - Transplanting mode

### 1.2.2 Resume the Last Task

It is used to automatically load and continue the latest job without configuring it.

To resume the last task, press **Resume Last Task** and **Less**. The system automatically loads the latest job.

### 1.2.3 Load a Task

It is used to load a task saved in the system or a flash disk, delete tasks, and export local tasks to a TF card or flash disk with TXT format or JBASE format.

Before loading a task, make sure the following:

- If you need to load an external task or export a local task, make sure a TF card or a flash disk has been inserted.
- If you need to export a local task or delete a task, make sure the job has been closed if the job you would like to export or delete is in use.



To load a task, do the following:

<u>ዝዘ</u> 🛜 盲 704	IB/S				<sup>~</sup> III 📶 R
	Local Task	Externa	l Task	Export Task	
Task Name	Start Time	Update Time	Task Mode	dth/Offset(L/R)	Operation Area
20210915154502	2021/09/15 15:45:02	2021/09/17 13:26:12	A+ Line	6.0/1.2m	0.0000Ha
20210915154116	2021/09/15 15:41:16	2021/09/15 15:41:16	Transplanting	3.0/1.8m	
20210915151013	2021/09/15 15:10:13	2021/09/15 15:40:27	AB Line	6.0/1.2m	0.0000Ha
20210906105059	2021/09/06 10:50:59	2021/09/06 10:50:59	Grid	6.0/1.2m	
20210901152602	2021/09/01 15:26:02	2021/09/01 15:26:02	Grid	6.0/1.2m	
20210901134909	2021/09/01 13:49:09	2021/09/01 13:49:09	Grid	7.0/0.0m	
20210901134845	2021/09/01 13:48:45	2021/09/01 13:48:45	Grid	7.0/0.0m	
20210831164022	2021/08/31 16:40:22	2021/08/31 16:40:22	Grid	5.0/0.0m	2
20210831163816	2021/08/31 16:38:16	2021/08/31 16:38:16	Grid	5.0/0.0m	
20210830105433	2021/08/30 10:54:33	2021/08/30 10:54:33	Grid	5.0/0.0m	

- 2. Do one of the following:
  - To load a local task, switch to **Local Task** page.
  - To load an external task, switch to **External Task** page.
- 3. Optional: To delete a local task or an external task, do the following:

**CAUTION:** This operation is irreversible. Please be careful.

- a. Do one of the following:
  - Press the target task in **Local Task** page, and press **Delete**.
  - Long press the task list, and check the target tasks, and press **Delete**.
- b. Press YES for confirmation.
- 4. Press the target task, and press **Load** to load a local task or an external task. **Implement Info** dialog box pops up:

	Impleme	ent Info	
Task Name	20210917132523		
Implement Name	Default		
	Swath Width	6.0	
	<ol> <li>Implement Width</li> </ol>	4	
	② Skip(+)/Overlap(-)	2.0	
	③ F(+)/B(-) Offset	0.0	
	④ L(-)/R(+) Offset	1.2	
CANCEL		ок	

- 5. Press dropdown box of Implement Name, and select the target implement.
- 6. Select a style for reloading task:
  - $\circ$  Resume task: to keep the previous task track and resume the task.
  - Start from head: to clear the previous task track and start a new task.



### 7. Optional: To export local tasks, do the following:

a. Switch to **Export Task** page:

	Local Task	External	Task	Export Task	
Task Name	Start Time	Update Time	Task Mode	h/Offset(L/R) St	Operation Area
20210915151013	2021/09/15 15:10:13	2021/09/15 15:40:27	AB Line	6.0/1.2m	0.0000Ha
20210830105014	2021/08/30 10:50:14	2021/08/30 10:50:14	AB Line	5.0/0.0m	
20210823171735	2021/08/23 17:17:35	2021/08/23 17:17:35	AB Line	5.0/0.0m	
202108231712	2021/08/23 17:12:01	2021/08/23 17:12:01	AB Line	5.0/0.0m	
20210823171137	2021/08/23 17:11:37	2021/08/23 17:11:37	AB Line	5.0/0.0m	
20210823170302	2021/08/23 17:03:02	2021/08/23 17:03:02	AB Line	5.0/0.0m	
20210819095837	2021/08/19 09:58:37	2021/08/19 09:58:37	AB Line	5.0/0.0m	
20210819095739	2021/08/19 09:57:39	2021/08/19 09:57:39	AB Line	5.0/0.0m	
20210819095721	2021/08/19 09:57:21	2021/08/19 09:57:21	AB Line	5.0/0.0m	
20210819095706	2021/08/19 09:57:06	2021/08/19 09:57:06	AB Line	5.0/0.0m	

b. Press the target task, and press **Export**. The target job is automatically exported to the root directory of the inserted TF card or flash disk.

### 1.2.4 Get a Task from the Server Platform

It is used to get a task from EAG server platform for remote control.

To get a task from the server platform, do the following:

1. Press Cloud+Terminal and



- 2. To load the target task, press the target task, and press **Load**.
- 3. Optional: To get a near task, press Get Near Task.
- 4. Optional: To delete the target task, select the target task, and press Delete.



# 1.3 Set Guidance Lines



#### View mode

•



the 3D view of the current working mode. In this mode, the vehicle will not move while the map will mode.



• North : in this mode, the vehicle will move while the map will not move. The upper of the MC5 is the north.



upper of the MC5 is the driving direction.

Zoom mode: you can zoom in or out the view with two fingers, and restore the default



view by pressing



#### Info bar

- Speed: the driving speed of the vehicle.
- Area: the area that has been finished.
- Direction: the direction of the vehicle.
- Line: when the target line is created, there will be a group of guidelines. 0 indicates the target line, a negative value indicates the guideline in the left of the line, and a positive value indicates the guideline in the right of the line.
- Time and date: the current time and date of the system.

Homepage: to return to the main software interface.

# CAUTION: With this way, the main menu Start Job changes to Resume Job.

#### 1.3.1 Use AB Line Mode

In this mode, the working track is a line and you can shift the guidance line if it is not the desired one instead of creating a new one.

To use AB line mode, do the following:

1. In the interface of selecting a working mode, press **AB Line** and **E**, and select the target implement name in **Implement Info** dialog box:



2. To set the current position as point A, press A.



3. To set point B, drive a certain distance, and press **B**. The system automatically generates AB guidance lines according to the swath width as follows:



- 4. **Optional:** If the AB guidance line is not the desired one, do one of the following:
  - To automatically shift the AB guidance line, drive the vehicle to the target position, and press **Align**. The system automatically shifts the AB guidance line.
  - To manually shift the AB guidance line, press **Shift**, and input a value. The AB guidance line shifts the set value.



- 5. Press Autopilot to engage automatic driving, and stop the vehicle when it reaches the plot tail.
- 6. Turn the vehicle around, engage automatic driving to enter any of AB guidance lines, and start your work.



#### 1.3.2 Use A+ Line Mode

To use A+ line mode, do the following:

In the interface of selecting a working mode, press Straight A+ and select the target implement name in Implement Info dialog box:

, and



- 2. To set the current position as point A, press A.
- 3. To set an angle for A+ guide line, do one of the following:
  - Turn the steering wheel, and press Angle.
  - Input a value in input box of **Angle**.

The system automatically generates A+ guidance lines according to the swath width as follows:



4. **Optional:** If the A+ guidance line is not the desired one, shift the line.





5. Optional: To check the working track, press

The area in green indicates that this area has been finished.



- 6. Press Autopilot to engage automatic driving, and stop the vehicle when it reaches the plot tail.
- 7. Turn the vehicle around, engage automatic driving to enter any of A+ guidance lines, and start your work.

#### 1.3.3 Use Pivot Mode

To use pivot mode, do the following:

1. In the interface of selecting a working mode, press **Pivot** and **E**, and select the target implement name in **Implement Info** dialog box:



🕀-survey

- 2. To set a guidance circle, do one of the following:
  - To create a fitting circle, press A to set the current position as point A, drive the vehicle in a curve, and press B. The system automatically creates a fitting circle according to curve AB.
  - To draw a circle, press **CENTER** to set the current point as the circle center, and drive the vehicle for a certain distance. The system automatically draws a circle with the distance as the radius.



- 3. **Optional:** If the guideline circle is not the desired one, shift the line.
- 4. **Optional:** To check the working track, press **Track**. The area in green indicates that this area has been finished.



- 5. Press Autopilot to engage automatic driving, and stop the vehicle when it reaches the plot tail.
- 6. Turn the vehicle around, engage automatic driving to enter any of guidance circles, and start your work.



### 1.3.4 Use Grid Mode

In the planned route, the route at the long side is a slower curve, and the other side is a pear-shaped curve. You need to appropriately slow down to 10 km/h below for the slower curve and 8 km/h below for the pear-shaped curve when driving the vehicle in curve.

It is suggested to do the following before using grid mode:

- Press main menu Calibrate Vehicle, and do the following:
  - a. Press Vehicle, and modify the value of parameter Min Turning Radius to **10**.

If you are not satisfied with the turn result, please increase it to **13**.

- b. Press Control Para, modify the grid value of line to 10, and curve to 3 in Line Acquisition page, and modify the value of P1 to 4 and I1 to 5 in PID page.
- To increase the overlapped area, set the width of implement to a value less than the actual width.

e.g. The actual width of implement is 7.3 m, it is suggested to set it to 6.8 m to increase the overlapped area.

• Drive the vehicle to the edge of the plot and turn the steering wheel 45° before setting points.

To use grid mode, do the following:

1. In the interface of selecting a working mode, press **Grid** and **E**, and select the target implement name in **Implement Info** dialog box:



- 2. To set point A, drive the vehicle to one corner of the plot, and press A.
- 3. To set point B, drive the vehicle to the second corner of the plot, and press B.
- 4. To set point C, drive the vehicle to the third corner of the plot, and press C.



5. To set point D, drive the vehicle to the fourth corner of the plot, and press D:



- 6. **Optional:** If the planned route at both ends of the ground is not fully covered, disengage automatic driving and drive the vehicle around the curve, drive the vehicle back to the red line when finished and follow the direction of the arrow to continue automatic driving.
- 7. Select a plot planning mode:
  - o Irregular plot
  - Regular plot
- 8. Press **Start**. The system automatically generates grid guidance lines: **Irregular plot**







9. **Optional:** If you are not satisfied with the result, press Left / Right to adjust the number of lines.

In general, for a 1000 m plot, the number of lines is 6 ~9.



10. **Optional:** To check the working track, press **Track** The area in green indicates that this area has been finished.



- 1. Press Autopilot to engage automatic driving, and stop the vehicle when it reaches the plot tail.
- 2. Turn the vehicle around, engage automatic driving to enter any of grid guidance lines, and start your work.

### 1.3.5 Use Contour Mode

Contour mode includes the following types and you can switch them conveniently:

- Equidistance curve (recommended): it guarantees the swath of the task with a slight deformation of the curve.
- AB curve: it guarantees the deformation of the curve unchanged without guaranteeing the swath of the task.
- Free curve: it is applicable to curves with large curvature.

To use contour mode, do the following:

 In the interface of selecting a working mode, press Contour and select the target implement name in Implement Info dialog box.





2. Select a type of contour mode:



- 3. To set the current point as point A, press **A**.
- 4. Drive the vehicle in an arc, and press **B**. The system automatically generates guidelines according to the track:



5. Optional: To adjust the arc position, press Left / Right.



- 6. Press Autopilot to engage automatic driving, and stop the vehicle when it reaches the plot tail.
- 7. Turn the vehicle around, engage automatic driving to enter any of contour guidance line, and start your work.

# -survey

#### 1.3.6 Land Measurement Mode

To use land measurement mode, do the following:

1. In the interface of selecting a working mode, press Land Measurement and



- 2. Select a way to define the plot edge:
  - **Middle**: the centerline of the vehicle.
  - Left: the leftmost of the implement.
  - Right: the rightmost of the implement.
- 3. Press Start.
- 4. Drive the vehicle around the plot and press **End** when the whole edge of the plot has been finished.

### 1.3.7 Use Transplanting Mode

To use transplanting mode, do the following:

- 1. In the interface of selecting a working mode, press **Transplanting** and and select the target implement name in **Implement Info** dialog box.
- 2. Press Start.



3. Drive the vehicle around the plot again:



- 4. **Optional:** If you would like to modify the route, press **Restart** and drive the vehicle around the plot.
- 5. Return to the start point and press Complete.

### 1.4 Configure the Implement

To configure the implement, do the following:

1. Press main menu Configure Implement:



- 2. **Optional:** To create an implement, do the following:
  - a. Press the dropdown box of Select Implement.
  - b. Press **New**, and enter a name for the new implement.



- 3. Set the following implement parameters:
  - Implement Width: the width of the implement.
  - **Skip(+)/Overlap(-)**: a positive value means the skipped distance while a negative value means the overlapped distance.
  - F(+)/B(-) Offset: the vertical distance between the rear axle shaft of the vehicle and the back of the implement. A positive value means the implement is installed in the front of the vehicle while a negative value means it is installed in the back of the vehicle.
  - L(-)/R(+) Offset: the distance between the vehicle centerline and the implement center. A positive value means the implement center is on the right of the vehicle centerline while a negative value means it is on the left of the vehicle centerline.
- 4. Press Calibrate Ridge:



- 5. Press **Calculate**. The system automatically calculates the result and fills it into the input boxes.
- 6. Press **I** for confirmation.



# 1.5 Calibrate the Vehicle

Correct vehicle calibration is the premise that the vehicle can achieve high-precision automatic driving. And it is required after assembling the whole system and before establishing a job.

The main interface of vehicle calibration is as follows:



Before doing vehicle calibration, make sure the symbol of satellite status in the upper right

RTK

III

is 🔍

, and the value after **RTK** (delay) is within 1 - 3.

To calibrate the vehicle, do the following:

- 1. Press main menu Calibrate Vehicle, and input the password.
- 2. Select a vehicle type:
  - Standard tractor
  - $\circ$  Combine
  - Transplanter



#### 3. Do as follows:



**CAUTION**: Calibrating the encoder is required only when the Control mode is set to **EWheel Steering with Encoder**.



### 1.5.1 Set the Vehicle

When setting the vehicle, please make sure all values are set accurately, which is the prerequisite for the accurate automatic driving.

To set the vehicle, do the following:



2. In Parameters page, set the following parameters:

CAUTION: All antenna related parameters are parameters related to the positioning antenna in the MC5 (hereinafter referred to as positioning antenna).

- **Antenna Height**: the distance between the positioning antenna and the bottom of the back wheel.
- Antenna F (+) / B (-) Offset: the distance between the center of the positioning antenna and the center of the back wheel:
  - If the positioning antenna is in the front of the center of the back wheel, please input a positive value.
  - If it is behind the center of the back wheel, please input a negative value.
- Antenna L (-) / R (+) Offset: the distance between the center of the positioning antenna and the central axis of the vehicle:
  - If the positioning antenna is in the right of the central axis, please input a positive value.
  - If it is in the left of the central axis, please input a negative value.
- **Wheelbase**: the distance between the center of the front wheel and the center of the back wheel. Please check the vehicle manual for this value.



- Antenna Orientation: the angle between the line connecting MC5 smart antenna and the UA35 GNSS antenna and the central axis of the vehicle.
  - If the positioning antenna is at the rear of the vehicle roof, the line is parallel to the central axis. Please use the default value 0°.
  - If the positioning antenna is on the left of the vehicle roof, the line is vertical to the central axis. Please input 90°.
  - If the positioning antenna is on the right of the vehicle roof, the line is vertical to the central axis. Please input 270°.

 $\Rightarrow$  CAUTION: 180° is not allowed. And it is suggested to set it to 0°.

- **Min Turning Radius**: it is the larger value between the left turning radius, calculated by turning the wheel to the left to the full extent at low speed, and the right turning radius, calculated by turning the wheel to the right to the full extent. Please check the vehicle manual for this value.
- 3. **Optional:** To set the IMU state and UA35 GNSS antenna, press **Others** to enter **Others** page, and do the following:

Built-in	0
External	0
Antenna Mode	
Single Antenna	0
Dual Antennas	0

#### IMU type

- **Built-in**: an external IMU is not installed on the cab.
- External: an external IMU is installed on the cab.

### **GNSS Mode**

- Single antenna: a US35 GNSS antenna is not used.
- Dual antennas: a UA35 GNSS antenna is used.
- 4. To save settings, press



#### 1.5.2 Select a Control Mode

**CAUTION:** Please restart the system each time you modify the control mode.

To select a control mode, do the following:

- 1. To enter Control Mode interface, press
- 2. Select one of the following control modes:
  - Hydraulic steering with Gyro-WAS
    - o E-wheel steering with Gyro-WAS
    - o E-wheel steering with encoder
- 3. To save settings, press

#### 1.5.3 Select the ECU Direction

It is used to select the correct cable direction (the direction of the bus connector on the MC5 (ECU-MAIN-CABLE)).

The top orientation of the MC5 is fixed to **UP** the direction of the logo on the MC5.

CAUTION: Please restart the system each time you modify the ECU direction.

To select the ECU direction, do the following:





- 2. Select one of the following cable direction according to the actual condition:
  - Left: the bus connector is in the left of the EUC.
  - **Right**: the bus connector is in the right of the ECU.
  - **Front**: the bus connector is in the front of the ECU.
  - **Back**: the bus connector is in the back of the ECU.
- 3. To save settings, press

After selecting the ECU direction, restart the MC5 without restarting the display.

#### 1.5.4 Calibrate the Sensor

During calibrating the sensor, please control the speed within 1 - 1.5 km/h.

To calibrate the sensor, do the following:

1. Drive the vehicle to an area of at least 30 m \* 50 m.



2. To enter Encoder Calibration interface, press.

音 8968/S		"III 📆 RTK
	Speed 3.21 km/h	
Attention: At least 30 m x 50	m area is required.	
Calibration steps:		
1. Click Start. The vehicle au	tomatically drives an S-shaped curve for	r about 30 m. (Please make sure
the speed is within 1 - 1.5 km	/h.)	
After the calibration is comp	leted, the result shows in the Result inpu	ut box.
2. Click Complete to finish th	e calibration.	
	Result:	
Start	Resolu	
Stop	Complete	

- 3. Click Start. The system automatically controls the vehicle to drive an S-shaped curve for about 30 m, and the result automatically fills in Result input box after finishing.
- 4. Press Complete to exit setting.



# 1.5.5 Set Roll and Pitch

It should be done in a flat and open area. Otherwise, the value of **Deviation** may exceed the allowable range ( $\pm 2.5$  cm) during automatic driving.

During setting roll and pitch, please keep the vehicle speed within 3 km/h  $\sim$  5 km/h and make sure your own safety.

To set roll and pitch, do the following:

1. To enter **Roll Pitch** interface, press

7 1 897B/S		<sup>**</sup> III <sup>**</sup> III <sup>**</sup> Ш RTK 3
Deviation 75.07 m	Speed 0.0km/h	Set A Set E
		Autopiloi On
		Complete
6-4		Roll
		Pitch

- 2. To set the current point as point A, press Set A.
- 3. To set point B, drive the vehicle at least 50 m, and press Set B.
- 4. Drive the vehicle a long distance, turn the vehicle around, drive the vehicle in the extended line of AB, and make sure the value of **Deviation** is within 5 cm before the vehicle reaches point B.

Deviation: the distance between the vehicle and line AB.

- 5. Press **Autopilot On** to engage automatic driving from point B to point A, and press **Autopilot Off** to disengage automatic driving when the vehicle reaches point A.
- 6. Drive the vehicle a long distance, turn the vehicle around, drive the vehicle in the extended line of AB, and make sure the value of **Deviation** is within 5 cm before the vehicle reaches point A.
- 7. Press **Autopilot On** to engage automatic driving from point A to point B, and press **Autopilot Off** to disengage automatic driving when the vehicle reaches point B.
- 8. Press Complete. The system automatically fills in input boxes of Roll and Pitch.
- 9. Press **Complete** to exit setting.

# **O-survey**

# 1.5.6 Set the Antenna Offset

During automatic driving, the speed should be controlled within 1.5 - 3 km/h.

To set the antenna offset, do the following:



1. Press

6.Antenna Offset, and carefully read calibration steps in the following interface:



 To enter Antenna Offset interface, press I KNOW. Antenna Offset interface shows:



If you are not sure about calibration steps during setting the turn back line, please press **Help**.

- **⊕**-survey
  - 3. To set point A and B, do the following:
    - a. To set the current point as point A, press Set A.
    - b. To set point B, drive the vehicle a certain distance, and press Set B.
  - 4. Drive the vehicle a certain distance, turn the vehicle around, and press **Autopilot On** to engage automatic driving from point B to point A,
  - 5. Stop the vehicle when the value of **Deviation** is less than  $\pm 1$  cm, and mark the location where is vertically outward 50 cm from the right real wheel.
  - 6. Drive vehicle a certain distance with automatic driving engaged, press **Autopilot Off** to disengage automatic driving, and turn the vehicle around.
  - 7. Press **Autopilot On** again to engage automatic driving, and do one of the following according to the value of **Deviation**:
    - $\circ~$  If it is less than  $\pm~1~$  cm at the marked location, stop the vehicle, and press **Autopilot Off** to disengage automatic driving.
    - If it is not less than ± 1 cm at the marked location, reverse the vehicle, and drive the vehicle to the marked location again.
       If it is still not less than ± 1 cm, repeat the operation or start from step 1 in another open area.
  - 8. Measure the distance between the marked location and the left rear wheel, and input the result in input box of **Measured Value**. The system automatically fills in the input box of **Antenna L(-)/R(+) Offset**.
  - 9. Press Complete to exit setting.

# 1.5.7 Set Control Parameters

It is used to set line acquisition, safety parameters and PID parameters. It is suggested to use default control parameters.

To set control parameters, do the following:



1. To enter Control Para interface, press



 Set related parameters about line acquisition. Range: 1 - 10.

🕀-survey

The smaller the value is, the higher frequency of steering wheel direction is.

3. To set safety parameters, press **Safety** to switch to **Safety** page, and set related parameters:



4. To set PID parameters, press **PID settings**, and set related parameters:

<	Line Ac	quisition	Safety	y		PID	
	P1	6		11	0		
			DEFAULT				





# 1.5.8 Reset the ECU

It is used to restore settings of vehicle calibration to factory settings.

**Warning:** This operation is irreversible. All data of vehicle calibration and sensor calibration will be cleared. Please be careful.



To reset the ECU, press

# 1.6 Set Communication Mode

To set communication mode, do the following:

1. Press main menu Communication Mode:

ATLAS
SBAS

- 2. To select a correction source, press **Correction Source**, and select one of the following:
  - Display
  - MC5
- 3. To connect Wi-Fi, press Wi-Fi, and select the target Wi-Fi.



4. In External Correction page, do the following:



- a. Do one of the following:
  - Select whether to enable Internal Radio.
  - Select whether to enable Ntrip.

CAUTION: With Ntrip enabled and bad network signal, please turn on hotspot of your mobile phone, and connect the ST6 display terminal to the hotspot.

- b. Select whether to enable **aRTK**.
   With it enabled, the receiver is able to generate RTK positions even if the RTK correction source becomes unavailable within the set aRTK age limit.
- c. Set differential age.
- d. Select whether to enable **SBAS**. SBAS: the wide-area differential augmentation system (satellite-based augmentation system).



5. In **Internal Correction** page, do one of the following:



- Select whether to enable ATLAS.
   With it enabled, please select a channel from one of the following:
  - Auto
  - 1545.855 MHz (Asia)
  - 1545.915 MHz (US)
  - 1545.905 MHz (EU)
- Select whether to enable SBAS.

#### 1.7 Diagnose

To start diagnosing the system, do the following:

- 1. Press main menu Diagnose.
- 2. Do the following:
  - Check satellite status.
  - o Check system parameters.
  - o Check system status.
  - Check network status.
  - Use remote assistance.



### 1.7.1 Check Satellite Status

To check satellite settings, press **Satellite Status** to switch to **Satellite Status** page, and check the following:

"11 🛜 🔒 704B/S					
Satellite Statu	System Parameters	System Status	Network Status	Remote Assistance	
UTC Time	Latitude	Longitue	ie -	Altitude	
2021/09/17 05:19:18	N31.08443512	E121.5303	9019	61.768m	
Solution Status	Speed	Directio	n	Accuracy	
AUT,NONE,0	0.0km/h	0.0*		1.075	
Distance to Base	GNSS SN	Display S	SN .	Wheel Angle	
0.0km	21409626	ST629010000f	d46d27f	0.0	
	G	iNSS Signal			
L1,L2,G1	I,G2,B1,B2,B3,B2B,E1B,E5A	,E5B,9,0,4,0,9,0,0,0,5,0,0,C	A,D,D,C,B,D,B,C,D,A		
	S	ubscription			
		GPS,L1,B3			

- UTC time
- Latitude, longitude and altitude: the coordinates of the current position.
- Solution Status: the current solution status.
- **Speed**: the current speed of the vehicle.
- **Direction**: the angle difference of the MC5 and the north direction.
- Accuracy: unit: m
- **Distance to Base**: the distance between the current position and the base station.
- **GNSS SN**: used for registration and authorization.
- **Display SN**: the display SN.
- Wheel Angle: the current angle of the wheel.
- **GNSS Signal**: the tracking GNSS and signal intensity.
- **Subscription**: GNSS authorization, Atlas accuracy, and expired time.

### 1.7.2 Check System Parameters

It is used to check the values of wheelbase, swath width, smooth, antenna height, antenna F(+)/B(-) offset, antenna L(-)/R(+) offset, antenna orientation, roll, pitch, WAS left, WAS

# e-survey

center, WAS right, radio frequency, GYRO, TB (X, Y and Z), implement F(+)/B(-) offset, implement L(-)/R(+) offset, control mode and encoder result.

To check system parameters, press **System Parameters** to switch to **System Parameters** page, and check related parameters:

"910 🤶 🔒 704B/S				
Satellite Sta	tus System Parameters	System Status Networ	k Status Remote Assistance	
Wheelbase	Swath Width	Smooth	Antenna Height	
2.33	3.0	3.0	2.78	
Antenna F(+)/B(-) Offset	Antenna L(-)/R(+) Offset	Antenna Orientation	Roll	
-0.15	0.0	0.0	0.21	
Pitch	WAS Left	WAS Center	WAS Right	
1.49	-20.0*,2800.0	2125.0	20.0*,1500.0	
Radio Frequency	GYRO,TB,X	GYRO,TB,Y	GYRO,TB,Z	
460.0125	0.000139,0.001867	0.000043,-0.005647	0.000357,-0.011059	
Implement Offset F(+)/B(-)	Implement Offset L(-)/R(+)	Control Mode	Encoder Result	
0.0	1.8	4	23.3,18.686	

# 1.7.3 Check System Status

To check system status, do the following:

1. Press System Status to switch to System Status page:



- 2. Check the following status:
  - ECU: including ECU serial port and GNSS serial port.
  - **Antenna**: including solution status and HDT course.
  - **Motor**: including connection, current, voltage and temperature.



- **E-wheel**: including the connection of the electrical steering wheel, current, voltage and temperature.
- 3. To check error logs for troubleshooting, press ERROR LOG.
- 4. To check the steering, press **STEERING CHECK**, and press < or > to adjust the wheel angle:



# 1.7.4 Check Network Status

To check network status, press **Network Status** to switch to **Network Status** page, and check the following:

Satellite Status	System Parameters	System Status	Network Status	Remote Assi
				-
Succeeded in logging in the	e platform			
Expired				
ST6 ICCID: 8986042510204	0046862			
MC5 ICCID: 89860620000	004506300			

- Connection status of the platform
- Status of the CORS account
- Connection status of the CORS
- Download speed
- Upload speed

### 1.7.5 Use Remote Assistance

To use remote assistance, press **Remote Assistance** to switch to **Remote Assistance** page.

# -survey

CAUTION: Before using it, please contact us.

# 1.8 Settings

To set system settings, do the following:

1. Press main menu **Settings**:

C Version
🔅 Brightness
Sound

- 2. Set the basic settings.
- 3. Authorize the system.
- 4. Check the system version.

### 1.8.1 Set Basic Settings

To set basic settings, set one of the following based on your need:

- Select the unit of speed: including km/h and mph.
- Select the unit of area: including Mu and Ha.
- Select a language.
- Select the working mode: including day and night.
- Adjust brightness.
- Adjust voice volume.

### 1.8.2 Authorize the System

It includes the following:

- Time authorization: to get the expiry date.
- Function authorization: to unlock functions including low speed, grid guidance mode and contour guidance mode.
- Atlas authorization: to get the expiry date of Atlas.



#### 1.8.2.1 Do Time Authorization

To do time authorization, do the following:

1. To enter **Time** page, press **Authorization**  $\rightarrow$  **Time**:

Will R	4º111			音 704B/S	
	Atlas	Function	Time		
		21409626		NSS SN	GNS
		Unauthorized		oiry Date	Expir
				ization Code	Authoriza

2. Press input box of Authorization Code, and input the authorization code.

3. Press **Expiry** data show automatically in input box of **Expiry Date**.

#### 1.8.2.2 Do Function Authorization

To do function authorization, do the following:

It is used to unlock function of slow speed work, grid mode and contour mode.

1. To enter Function page, press Authorization  $\rightarrow$  Function:

GNSS SN		21409626		
Authorized Function		Slow Mode, Grid, Con	tour	
Authorization Code	FU34MHRXPD4NUWW8KEPU			

2. Press input box of Authorization Code, and input the authorization code.



3. Press Authorized function shows automatically in input box of Authorized Function.

#### 1.8.2.3 Do Atlas Authorization

To do Atlas authorization, do the following:

1. To enter Atlas page, press Authorization  $\rightarrow$  Atlas:

"୩୦୦୦ 🛜 🔒 704B/S			<sup>40</sup> 111	THIN RTK2
	Time	Function	Atlas	
GNSS SN		21409626		
Expiry Date		Unauthorized		
Authorization Code				

- 2. Press input box of Authorization Code, and input the authorization code.
- 3. Press . Expiry data show automatically in input box of **Expiry Date**.

### 1.8.3 Check the System Version

It includes check the software version and firmware version, and update them through the system or USB if they are not the latest version.

If you need to update the software version and firmware version through the USB, before checking the system version, insert a USB with the latest versions, and make sure the firmware files are put in directory **Root directory/devfrm** of the USB and firmware names are as follows:

- ECU: AUP\_MC5RC.psr
- E-wheel: EES\_E2910.bin
- GNSS board: V28\_BRD\_FRM.bin
- iMM1: iMM1\_FRM.bin



To check the system version, do the following:

1. Press Version:



- 2. **Optional:** Check information of the current software version, firmware and GNSS board.
- 3. To check the software version, press **Check Software Version** / **Update Software by USB**. The system automatically checks if the current software version is the latest one. The system automatically upgrades the software if it is not the latest one.



- 4. To check the firmware version, do the following:
  - a. Press **Check Firmware Version** / **Update Firmware by USB**. The system automatically checks if the current firmware version is the latest one and starts to download firmware and the following interface shows if not:

"때 🛜 🔒 704B/S	** <b>11</b>	COLO RTK2
Update steps:		
1. Confirm the item to update, and press Start.		
2. Press Start. Updating starts.		
Note: During updating, please do not power off ECU and display, restart or remove USB.		
3. Restart the system after updating.		
ECU EWHEEL GNSS IMM1 Start update		

- b. Check the target item to update (including ECU, E-wheel, GNSS board and iMM1).
- c. Press Start. Updating starts.

Caution: During updating, please do not power off ECU and display, restart or remove USB.

Alternatively, to update the firmware through Web UI on your PC, see Web UI for details.